

# H100

## Accessories Guide



### STD. Spec.

#### Adapter



##### PWR-H100-5V2A-CN

H100 adapter(CN), WH, I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



##### PWR-H100-5V2A-EU

H100 adapter(EU), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



##### PWR-H100-5V2A-UK

H100 adapter(UK), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



##### PWR-H100-5V2A-US

H100 adapter(US), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.

#### USB Cable



##### DC-H100-TypeC

1.0 meter Type-C cable


#### Lanyard



##### SG-H100-LYD-WT

H100 lanyard, White

#### Sim Tray Ejector



##### SIM-TRAY-EJECTOR

Sim tray ejector

### Optional

#### Charging Cradle



##### CRD-H100-SCC

H100 charging cradle can charge one device, use with DC-H100-TypeC cable.


#### Charging Rack



##### RACK-CC-8

Each unit of the charging rack has various levels and can charge up to 8 devices at a time, use with charging cradle. The quadrate alloy cradle is elegant and rugged. You can have tens of devices charged on several charging racks. It saves space and time, ideal for indoor use. Applicable models: C6000, H100, C70, C71, C72 (without UHF module and pistol grip).

#### Charging cradle adopts magnetic connect



##### CRD-H100-MCC

H100 charging cradle adopts magnetic connect, it supports joint charging of 4 device, use with DCPWR-H100-12V5A-XX adapter.

#### Adapter



##### DCPWR-H100-12V5A-CN

H100 adapter(CN), I/P: 100-240V, O/P: 12V5A, DC